



SAM460ex
power for your embedded ideas.
www.sam4x0.com



U-Boot updater guide 460 v1.0 – Mar 21, 2011

WARNING!

***Upgrading the Sam460ex firmware is potentially dangerous.
If something should go wrong during the update, it might leave your system unusable.
In case this should happen, send an email to the following address:
support@acube-systems.com
and ask for help on how to solve the problem.***

How to update U-Boot on a Sam460ex board:

Burn the downloaded ISO image on a CD using your preferred burning software.
Do not select "Bootable CD" or any similar option on the burning software.

When the CD is ready, insert it into the CD/DVD reader connected to your Sam board, and press Reset on your computer case.
If the cdrom is the first bootable device, the Updater CD will auto start (otherwise change the boot devices priority accordingly)

Press ENTER at the "Select Boot Option".

Once the image has booted, you will be presented with a warning message.
If you wish to continue with the update, press SPACE.

Warning: pressing SPACE the re-flashing process starts immediately.

The re-flashing process takes only a few seconds and in case the updater finds any problem, it will notify them. After the update is finished, the updater will output a few lines of information and ask you to reset the machine.

To verify if you reflashed correctly to the new U-Boot version, interrupt the boot process, enter the prompt and type "**version**"

```
] version
```

You will see an output similar to this:

```
U-Boot 2010.06.04 (Mar 21 2011 - 11:10:35)
```

ACube Systems S.r.l.

Via Tabacco, 58 - 36061 Bassano del Grappa (VI) – Italy
tel. +39 0424 393120 fax +39 0424 393119 – info@acube-systems.com – www.acube-systems.biz
C.f. 03367150244 - VAT ID 03367150244 - REA VI-319762

U-boot 2010.06.04 – Mar 21, 2011

What's new:

- changed AHB bus setup, this fixes the use of the onboard SATA2 port with the sam460sata.device on AmigaOS4.1
- improved DDR2 setup:
- improved Radeon HD4650 setup
- fixed a bug in the PCI-E 1x/SATA2 menu

Alternative way to update U-Boot on your Sam460ex

If, for any reason, you cannot use the ISO image to update U-Boot, you can use TFTP.

This alternative way requires a second machine running a TFTP server (for example, on OS4Depot there is a TFTP server for AmigaOS4)

Copy the file **updater-460** on your TFTP server directory.

Stop the boot sequence on the Sam460ex and enter the U-Boot prompt by pressing **ESC**.

Execute the **menu** command.

Select the **Boot Sequence / Network Boot Options** menu.

Set the **Server TCP/IP Address** field to the address of the machine running the TFTP server.

Set the **Local TCP/IP Address** field to the address of your Sam in the same network of the TFTP server.

Select **Save setting and exit**.

Now you're back at the U-Boot prompt, execute the following command:

tftp 500000 updater-460

U-boot will load the file over network.

Once loading is finished, execute the command **bootm** and follow the on screen instructions.